

MESHGUARD CLEANING GUIDE

To ensure you get the most out of your MeshGuard Windows & Gates, we recommend regular cleaning to conserve the decorative appearance and to reduce corrosion strain.

If the MeshGuard Windows & Gates are not cleaned regularly the soiling process can be accelerated and may lead to irreparable surface defects and loss of the decorative appearance.

The mesh acts as a filter for air and can trap dust, dirt, salt, moisture and airborne impurities, resulting in marks and stains. Removing these impurities through regular maintenance is essential.

Cleaning Instructions

- Use warm water and a soft, non-abrasive brush or cloth
- Only use clean water, with slight additives of neutral washing agents (pH 7)
- To remove greasy, oily or sooty substances, make use of a white spirit, free of aromatic compounds or isopropyl alcohol
- Do not use solvents containing ester, ketones, polyhydric alcohol, aromatics, ethylene glycol or halogenated hydrocarbon
- Do not use scratching or abrasive agents
- Do not use strong acids or alkaline detergents
- Do not use detergents of unknown compositions
- Keep the exposure period to detergents to a maximum of one hour - the cleaning process can be repeated after 24 hours
- Rinse with clean cold water immediately after every cleaning
- For fine-textured effects use a fiber-free cloth and if needed a soft, non-surface-damaging brush
- Keep the track of sliding screens clean of dust and dirt

Frequency of cleaning

Environment	Description	Cleaning Intervals
Mild	More than 10km from beachfront or sheltered bay	Every 6 months
Moderate	Within 1km to 10km of beachfront or sheltered bay	Every 2 to 3 months
Marine	Within 500m of beachfront or within 100m to 1km of sheltered bay	Every 2 to 4 weeks
Severe Marine	Within 500m of beachfront or 100m of sheltered bay	Every 1 to 2 weeks

Some installations may require extra maintenance due to local environment conditions