

CLEANING INSTRUCTIONS

How to clean your SheerGuard Transparent Security Gates and Clear Burglar Bars

The basic cleaning agent for all SheerGuard polycarbonate products is **lukewarm** water using a **soft microfibre** (dust) cloth to loosen any dirt and grime, then dry with a soft cloth to prevent water spots.

A gentle wipe is required, do not rub too rigorously as this may leave fine scratches on the surface.

No detergents or any cleaning products are required.

